

Trainings ▾

General Information

The water-in-fuel (WIF) sensor is built into the fuel filter. You can **not** remove the WIF sensor for cleaning or service. You can **only** change it by changing the fuel filter. It can be drained of water by opening the petcock at the bottom of the fuel filter. Refer to Procedure 006-011 in the ISM/QSM11 Troubleshooting and Repair Manual, Bulletin No. 3666322 (</qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/3666322.html>).

