

FAULT CODE 143 - Engine Oil Rifle Pressure - Data Valid But Below Normal Operating Range - Moderately Severe Level

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Check for Fault Code 143.	Active or inactive counts of Fault Code 143?

STEP 1. Check the fault codes

STEP 1A. Check for Fault Code 143.

Conditions :

- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step

Check the fault codes. • Use INSITE™ electronic service tool to read the fault codes.	Active or inactive counts of Fault Code 143? YES Repair : Reference the Lubricating Oil Pressure Low troubleshooting symptom tree in the ISM, ISMe, and QSM11 Service Manual, Bulletin 3666322.	Appropriate troubleshooting symptom tree
	Active or inactive counts of Fault Code 143? NO	Repair complete