

FAULT CODE 173 - Fuel Control Rack Stuck

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check for active fault codes.	
	STEP 1A. Read the fault codes.	Fault Code 166 active
STEP 2.	Clear the fault codes.	
	STEP 2A. Disable the fault code.	Fault Code 173 inactive
	STEP 2B. Clear the inactive fault codes.	All fault codes cleared

STEP 1. Check for active fault codes.

STEP 1A. Read the fault codes.

Conditions : Turn keyswitch ON.		
Action	Specification/Repair	Next Step
Read the fault codes. Use INSITE™ electronic service tool to read the fault codes.	Fault Code 166 active	Fault Code 166
	Replace the fuel pump. Refer to Procedure 005-012 in Section 5. (/qs3/pubsys2/xml/en/procedures/57/57-005-012.html)	2A

STEP 2. Clear the fault codes.

STEP 2A. Disable the fault code.

Conditions :

- Connect all components.
- Turn keyswitch ON.

Action**Specification/Repair****Next Step**

Disable fault code.

Fault Code 173 inactive

2B

- Start the engine and let it idle for 1 minute.
- Use INSITE™ electronic service tool to verify that the fault.

Verify that all steps have been completed. If all steps have been completed, then follow the technical escalation process.

Escalate or call for assistance.

STEP 2B. Clear the inactive fault codes.**Conditions :**

- Connect all components.
- Turn keyswitch ON.

Action**Specification/Repair****Next Step**

Clear the inactive fault codes.

All fault codes cleared

Repair complete

- Use INSITE™ electronic service tool to clear the inactive fault codes.

Troubleshoot any remaining active fault codes.

Appropriate troubleshooting charts