

Fault Code: 135


Oil Pressure Sensor (OPS) Circuit

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 135 PID(P): SPN: FMI: Lamp: SRT: 00-352	High voltage detected at engine oil pressure sensor signal pin 12 of the engine harness Electronic Control Module (ECM) Connector.	No effect on performance. Common Warning output is energized.

©Cummins Inc



Circuit Description

The OPS monitors oil pressure and passes information to the ECM through pin 12 of the engine harness.

The ECM monitors the voltage on pin 12 and expects to see the voltage vary between 0.5 and 4.5

VDC during normal engine operation.

Voltage above 4.89 VDC on pin 12 will trip Fault Code 135 and can be caused by shorts in the supply, signal, or return wires, an open in the return wire or a failed sensor.

Component Location

The OPS is located on the left bank of the engine block above the fuel pump.

Shoptalk

Does the fault occur only in cold weather? If so, allow the oil to warm up and see if the fault goes inactive.

Warnings and Cautions

CAUTION

To avoid pin and harness damage use the following test leads when taking a measurement:
Part No. 3822758 - male Deutsch/Cannon/Metri-Pack test lead.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the oil pressure sensor.	
	STEP 1A. Inspect the oil pressure sensor and engine harness connector pins.	No damaged pins
	STEP 1B. Check the ECM oil pressure supply voltage.	4.75 to 5.25 VDC
	STEP 1C. Check the ECM oil pressure signal voltage.	0.42 to 0.58 VDC
STEP 2.	Check the engine harness.	
	STEP 2A. Inspect the engine harness adaptor cable and the ECM connector pins.	No damaged pins

STEPS		SPECIFICATIONS
	STEP 2A-1. Inspect the engine harness and engine harness extension cable(s) connector pins.	No damaged pins
	STEP 2B. Check for a short circuit from pin to pin.	More than 100k ohms
	STEP 2B-1. Check for a short circuit from pin to pin in the engine harness adaptor cable and extension cable(s).	More the 100k ohms
	STEP 2C. Check for an open circuit in the return wire.	Less than 10 ohms
	STEP 2C-1. Check for an open circuit from pin to pin in the engine harness adaptor cable and extension cable(s).	Less than 10 ohms
STEP 3.	Clear the fault code.	
	STEP 3A. Disable the fault code.	Fault Code 135 inactive
	STEP 3B. Clear the inactive fault codes.	All faults cleared

STEP 1. Check the oil pressure sensor.

STEP 1A. Inspect the oil pressure sensor and engine harness connector pins.

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller **not** in the diagnostic mode.
- Disconnect the engine harness connector from the oil pressure sensor.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

	No damaged pins	1B
	Repair the damaged pins Repair or replace the engine harness or the oil pressure sensor, whichever has the damaged pins. • Repair the engine harness. Refer to Procedure 019-203 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the engine harness. Refer to Procedure 19-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the oil pressure sensor. Refer to Procedure 019-066 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Dry the connector by using an electrical contact cleaner, Part No. 3824510. • Replace the connector seal.	3A
• bent or broken pins • pushed back or expanded pins • corroded pins • moisture in or on the connector • missing connector seal.		

STEP 1B. Check the ECM oil pressure supply voltage.

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller in the diagnostic mode.

Action	Specification/Repair	Next Step
• Install the oil pressure sensor breakout cable, Part No. 3824775, between the sensor and the sensor harness connector. • Measure the supply voltage by installing the breakout cable's supply (pin A) and return (pin B) connectors into the multimeter.	4.75 to 5.25 VDC	1C
		2A

STEP 1C. Check the ECM oil pressure signal voltage.**Conditions :**

- Stop/Run switch in the "STOP" position.
- Controller in the diagnostic mode.

Action	Specification/Repair	Next Step
• Measure the signal voltage by installing the breakout cable's signal (pin C) and return (pin B) connectors into the multimeter.	0.42 to 0.58 VDC	2A
	Replace oil pressure sensor Refer to Procedure 019-066 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.	3A

STEP 2. Check the engine harness.**STEP 2A. Inspect the engine harness adaptor cable and the ECM connector pins.**

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller **not** in the diagnostic mode.
- Disconnect the engine harness adaptor cable from the ECM.

Action	Specification/Repair	Next Step
• bent or broken pins • pushed back or expanded pins • corroded pins • moisture in or on the connector.	No damaged pins	2A-1
	Repair the damaged pins Repair or replace the engine harness adaptor cable or ECM, whichever has the damaged pins. • Repair the engine harness adaptor cable. Refer to Procedure 019-240 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the engine harness adaptor cable. Refer to Procedure 019-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the ECM. Refer to OEM Procedures. • Dry the connector by using electrical contact cleaner, Part No. 3824510.	3A

STEP 2A-1. Inspect the engine harness and engine harness extension cable(s) connector pins.

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller **not** in the diagnostic mode.
- Disconnect the engine harness from the engine harness extension cable(s).

Action	Specification/Repair	Next Step
• bent or broken pins • pushed back or expanded pins • corroded pins • moisture in or on the connector.	No damaged pins	2B
	Repair the damaged pins Repair or replace the engine harness or the engine harness extension cable(s), whichever has the damaged pins. • Repair the engine harness or the engine harness extension cable(s). Refer to Procedure 019-240 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the engine harness or the engine harness extension cable(s). Refer to Procedure 019-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Dry the connector by using electrical contact cleaner, Part No. 3824510.	3A

STEP 2B. Check for a short circuit from pin to pin.

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller **not** in the diagnostic mode.
- Disconnect the engine harness adaptor cable from the ECM.
- Disconnect the engine harness from the OPS.
- Disconnect the engine harness from the coolant temperature sensor.

Action	Specification/Repair	Next Step
• Measure the resistance from the engine harness adaptor cable connector pin 12 to all other pins in the engine harness adaptor cable connector. • Measure the resistance from the engine harness adaptor cable connector pin 13 to all other pins in the engine harness adaptor cable connector. • Measure the resistance from the engine harness adaptor cable connector pin 11 to all other pins in the engine harness cable connector.	More than 100k ohms	2C
		2B-1

STEP 2B-1. Check for a short circuit from pin to pin in the engine harness adaptor cable and extension cable(s).

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller **not** in the diagnostic mode.
- Disconnect the engine harness adaptor cable from the ECM.
- Disconnect the engine harness from the engine harness extension cable(s).

Action	Specification/Repair	Next Step
--------	----------------------	-----------

• Measure the resistance from the engine harness adaptor cable and engine harness extension cable(s) connector pin 12 to all other pins in the connector. • Measure the resistance from the engine harness adaptor cable and engine harness extension cable(s) connector pin 13 to all other pins in the connector. • Measure the resistance from the engine harness adaptor cable and engine harness extension cable(s) connector pin 11 to all other pins in the connector.	More than 100k ohms Repair or replace the engine harness. • Repair the engine harness. Refer to Procedure 019-240 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the engine harness. Refer to Procedure 019-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.	3A
---	--	------------------

Repair or replace the engine harness adaptor cable or engine harness extension cable(s), whichever is found faulty

- Repair the engine harness adaptor cable or engine harness extension cable(s). Refer to Procedure 019-240 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.
- Replace the engine harness adaptor cable or engine harness extension cable(s). Refer to Procedure 019-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.

3A

STEP 2C. Check for an open circuit in the return wire.

Conditions :

- Stop/Run switch in the "STOP" position.
- Controller **not** in the diagnostic mode.
- Disconnect the engine harness adaptor cable from the ECM.
- Disconnect the engine harness from the OPS.

Action

Specification/Repair

Next Step

Measure the resistance from engine harness adaptor cable connector pin 13 to pin B of the OPS connector on the harness side.	Less than 10 ohms	3A
		2C-1

STEP 2C-1. Check for an open circuit from pin to pin in the engine harness adaptor cable and extension cable(s).

- Conditions :**
- Stop/Run switch in the "STOP" position.
 - Controller **not** in the diagnostic mode.
 - Disconnect the engine harness from the engine harness extension cable(s).
 - Disconnect the engine harness adaptor cable from the ECM.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

• Measure the continuity of pin 13 of the engine harness adaptor cable connector and any engine harness extension cables.	Less than 10 ohms Repair or replace the engine harness. • Repair the engine harness. Refer to Procedure 019-240 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184. • Replace the engine harness. Refer to Procedure 019-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.	3A
---	--	------------------

Repair or replace the engine harness adaptor cable or engine harness extension cable(s), whichever is found faulty

- Repair the engine harness adaptor cable or engine harness extension cable(s). Refer to Procedure 019-240 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.
- Replace the engine harness adaptor cable or engine harness extension cable(s). Refer to Procedure 019-043 in the Troubleshooting and Repair Manual QST Fuel System QST30 G-Drive Engine Series, Bulletin No. 3666184.

3A

STEP 3. Clear the fault code.

STEP 3A. Disable the fault code.

Conditions :

- Connect all components.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

- connect all components - start the engine and idle for one minute - verify that Fault Code 135 is inactive.	Fault Code 135 inactive	3B
	Return to troubleshooting steps or contact your local Cummins Authorized Repair Location if all steps have been completed and checked again.	1A

STEP 3B. Clear the inactive fault codes.

Conditions :

- Connect all components.

Action	Specification/Repair	Next Step
Erase the inactive fault codes using INSITE™, Part No. 3825145. NOTE: The datalink connector is located on the right bank of the flywheel housing.	All faults cleared	Repair complete
	Troubleshoot any remaining active fault codes.	Appropriate troubleshooting chart