

Trainings ▾

General Information

Service Mode

When Centinel™ is placed into the service mode, the oil control valve is continuously cycling independent of fuel consumption data.

The following is a general procedure for putting the Centinel™ module into the service mode:

- Turn the keyswitch OFF.
- Calibration plug installed.
- Turn the keyswitch ON.
- Start the engine.
- Remove the calibration plug and install the service plug. Look for the green LED to flash.

Note : If the engine is left running while attempting to exit the service mode, it can take up to 4 minutes to exit the service mode.

To exit the service mode, remove the service plug and install the required calibration plug.

- Turn the keyswitch OFF.
- Service plug **not** installed.
- Turn the keyswitch ON.
- Start the engine.
- Install the service plug.

Note : If the engine is left running while attempting to exit the service mode, it can take up to 4 minutes to exit the service mode.

To exit the service mode, remove the service plug.