

Trainings ▾

General Information

This procedure is for engines with 4 valves per cylinder only.

©Cummins Inc.

Remove

Note : Make note of the crosshead location and orientation. If the crossheads are reused, they must be installed in their original location and orientation.

Remove the crossheads.

