

Trainings ▾

Install

⚠ CAUTION ⚠

Be sure the gasket is correctly aligned with holes in the cylinder block. If the gasket is not correctly engine damage can result.

Install the new head gasket.

Note : Never reuse the old head gasket. Always use a new head gasket to prevent leakage.

