

Trainings ▾

General Information

Fuel Injection Pump Idle Adjustment Screws

The idle adjustment screw provides a stop for the lever at low speed. The adjustment screw can be used to increase idle speed for accessory loading or, if required, to lower the idle speed.

The high-speed screw is set at the factory and can **only** be adjusted at a certified fuel pump shop.

A - Idle Screw

B - High-Idle Screw.

