


Trainings ▾

Preparatory Steps

⚠ WARNING ⚠


Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

- Disconnect the batteries.




Remove

Use a hoist or lifting fixture to support the front of the engine.
Remove the capscrews from the front engine mount.




Remove the four mounting capscrews and the front engine support.



Clean and Inspect for Reuse

⚠ WARNING ⚠

When using a steam cleaner, wear protective clothing, and safety glasses or a face shield. Hot steam can cause serious personal injury.



⚠ WARNING ⚠


Wear appropriate eye and face protection when using compressed air. Flying debris and dirt can cause bodily injury.

Use steam or solvent to clean the front engine support.

Dry with compressed air.

Inspect the support for cracks or damage.


If the support is cracked, it **must** be replaced.



Install

Install the front support and mounting capscrews.

Torque Value: 68 n•m [50 ft•lb]




Lower the front of the engine.

Install the front engine mount capscrews.

Tighten the capscrews to the manufacturer's specifications.

Remove the lifting fixture or hoist from the front of the engine.



Finishing Steps

⚠ WARNING ⚠

Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

- Connect the batteries.

