

Trainings ▾

Specifications

Lubricating Oil Pressure at Idle (minimum allowable) Lubricating Oil Pressure at Rated (minimum allowable) Regulating Valve Opening Pressure

69 kPa [10 psi] 207 kPa [30 psi] 449 kPa [65 psi]

Lubricating Oil Capacity

Standard Pan Only

B3.9 9.5 liters [10 qt] B5.9 14.2 liters [15 qt]

Lubricating Oil Capacity

Total System - Liters [U.S. qt]

B3.9 11 liters [11.6 qt] B5.9 16.4 liters [17.3 qt]

Lubricating Oil Capacity

Low to High

B3.9 0.9 liter [1 qt] B5.9 1.9 liters [2 qt]

Note : If the type/oil capacity of the oil pan is not known:

1. Contact a local Cummins Distributor/Dealer
2. Determine the capacity of the oil pan option for the engine being serviced by using QuickServe OnLine and the engine serial number
3. Fill the lubricating oil pan to the smallest oil pan capacity listed for the engine being serviced. Then add 0.95 liters [1 qt] of oil at a time until it reaches the high mark on the dipstick. Record the number of quarts added so that capacity is known the next time the oil is drained.