

Trainings ▾

General Information

Complete the following steps after each oil change, or after the engine has been shut down for more than 30 days to make sure the engine receives the correct oil flow through the lubricating oil system.

1. Disconnect the electrical wire from the fuel pump solenoid.
2. Rotate the crankshaft, using the starting motor, until oil pressure appears on the gauge or the warning lamp goes out.
3. Connect the electrical wire to the fuel pump solenoid valve.
4. Start the engine. Refer to 101-014 (</qs3/pubsys2/xml/en/procedures/40/40-101-014-om-mar.html>) (Normal Starting Procedure).

