

Trainings ▾

Install

Install the fuel filter head bracket and the mounting capscrews.

Tighten the mounting capscrews.

Torque Value: 47 n•m [35 ft-lb]

