

Trainings ▾

Install

Use a new gasket to install the heater housing.

Install the four mounting capscrews and tighten.

Torque Value: 54 n•m [40 ft-lb]

Connect the electrical wiring to the heater, if used.

