

Trainings ▾

Install

Install the air shutoff valve. Refer to Procedure 019-386 in the Troubleshooting and Repair Manual, CM870 Electronic Control System, ISM Engines, Bulletin 4021381 (</qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021381.html>).

Install the two mounting capscrews and the turbocharger control shutoff valve filter head to the mounting bracket.

Torque Value: 45 n•m [33 ft-lb]

