

Trainings ▾

Install

Install the hose at the EGR mixer inlet.

Install a new o-ring between the EGR mixer and the air intake connection.

Install the EGR mixer.

Install and tighten the capscrews.

Torque Value: 20 n•m [15 ft-lb]

Install the EGR mixer bracket. Loosely install the four capscrews.

Tighten capscrews in a criss-cross fashion.

Torque Value: 20 n•m [15 ft-lb]

