

Trainings ▾

Remove

Remove the capscrews at the three bolt flange between the EGR mixer and the air intake horn.

Remove the capscrews at the EGR mixer support bracket.

Remove the EGR mixer.

Remove the mixer support bracket.

Remove the EGR return tube hose.

