

Trainings ▾

Remove

Remove the mounting capscrews.

Remove the EGR pressure sensor adapter.

