

Trainings ▾

Install

Remove capscrew (1) from the gear cover.

Use the capscrew to install the coolant outlet clamp and tube to the engine.

Torque Value: 20 n•m [15 ft-lb]

Install a new rubber grommet on the air compressor tube, and install and tighten the tube connection to the air compressor fitting (2).

Torque Value: 20 n•m [15 ft-lb]

