

Trainings ▾

Remove

Remove the inlet tube (1) and fitting (2).

Remove the outlet tube clamp capscrew (3) and the tube.

