

Trainings ▾

Select Service Tools

Recommended Cummins® Service Tools

- No Cummins® service tools required.

Additional Service Items

- No additional service items required.

Maintenance Check

Note : Depending on the application, it is possible engines will **not** be equipped with an air compressor.

Inspect the compressor housing for cracks and damage.

Inspect the hydraulic pump couplings for cracks, wear, or other damage, if equipped.

Inspect the air plumbing for splits or cracks.

Inspect the air compressor mounting nuts, including support bracket, for loose or damaged hardware.

Operate the engine and check for correct compressor operation.

Check for air, oil, and coolant leaks.

Torque Value:

Mounting 18 mm 77 n•m [57 ft-lb]

Torque Value:

Bracket 10 mm 45 n•m [33 ft-lb]



