

Trainings ▾

General Information

The air starting motor system (tanks, line sizes, and valves) is designed and installed by the original equipment manufacturers and the starting motor suppliers. Reference any questions about the air starting systems to the manufacturer.

- Do **not** operate the air starting motor with air pressure lower than 480 kPa [70 psi].
- Maintain the air starting motor according to the manufacturer's recommendations.
- For maximum efficiency, the hoses, tubes, and lines **must not** leak.
- Refer to the OEM service manual and manufacturer manuals for specific information regarding the starting motors, valves, and systems.