

Trainings ▾

Remove

Remove and discard the 18 Torx™ head capscrews.

Remove the block stiffener plate from the chassis.

Torx™ capscrews require a size 45 Torx™ socket.

