

Trainings ▾

Inspect

Check the torque on the engine-mounting nuts and bolts. Tighten any that are loose. Refer to the OEM service manual or manufacturer for torque specifications.

Inspect the rubber for deterioration and age hardening. Replace any broken or lost bolts, capscrews, or damaged rubber.

