

FAULT CODE 253 - Oil Level - Engine Protection

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check for multiple fault codes.	
	STEP 1A. Read the fault codes.	Fault Code 252 inactive?
STEP 2.	Check the oil level.	
	STEP 2A. Verify the oil level.	Oil level correct?
STEP 3.	Clear the fault codes.	
	STEP 3A. Disable the fault code.	Fault Code 253 inactive?
	STEP 3B. Clear the inactive fault codes.	All fault codes cleared?

STEP 1. Check for multiple fault codes.

STEP 1A. Read the fault codes.

Conditions : Turn keyswitch ON.		
Action	Specification/Repair	Next Step
Read the fault codes. Use INSITE™ electronic service tool to read the fault codes.	Fault Code 252 not active?	2A
		Multiple fault code trees

STEP 2. Check the oil level.

STEP 2A. Verify the oil level.

Conditions :

- Turn keyswitch OFF.

Action	Specification/Repair	Next Step
Verify the oil level using the oil dipstick.	Oil level correct? Replace the oil level sensor. Refer to Procedure 019-056 in Section 19. (/qs3/pubsys2/xml/en/procedures/19/19-019-056.html)	3A
	Fill the engine lubricating oil to the appropriate level. Reference the Troubleshooting and Repair Manual, QSK19 Series Engines, Bulletin 3666098, the Troubleshooting and Repair Manual, QSK23 Series Engines, Bulletin 4021375, the Troubleshooting and Repair Manual, QSK45 and QSK60 Series Engines, Bulletin 3666261, or the Troubleshooting and Repair Manual, QSK78 Series Engines, Bulletin 3666727.	3A

STEP 3. Clear the fault codes.

STEP 3A. Disable the fault code.

Conditions :

- Connect all components.
- Turn keyswitch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Disable the fault code. - Start the engine and let it idle for 1 minute. - Verify that Fault Code 253 is inactive.	Fault Code 253 inactive?	3B
	Return to the troubleshooting steps or contact a Cummins® Authorized Repair Location if all steps have been completed and checked again.	1A

STEP 3B. Clear the inactive fault codes.

Conditions :

- Connect all components.
- Turn keyswitch ON.

Action	Specification/Repair	Next Step
Clear the inactive fault codes. Use INSITE™ electronic service tool to clear the inactive fault codes.	All fault codes cleared.	Repair complete
	Troubleshoot any remaining active fault codes.	Appropriate troubleshooting charts