

Shutdown Unit Buzzer Does Not Activate With Fault

Symptoms

- Fault code registered with no activation of shutdown unit buzzer.

How To Use This Tree

This symptom tree can be used to troubleshoot a malfunction. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

The shutdown unit input signals are switches. These switches are normally open. They are closed when activated. The buzzer is internal to the shutdown unit and has no external wiring.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Check for active fault codes.	Active fault codes?
STEP 2.	Check the shutdown unit.	
	STEP 2A. Check for buzzer function at the shutdown unit.	Does buzzer function?
STEP 3.	Clear the fault codes.	
	STEP 3A. Clear the inactive fault codes.	All fault codes cleared?

STEP 1. Check the fault codes.

STEP 1A. Check for active fault codes.

Conditions :

- Turn keyswitch ON.
- Check the control panel for active fault codes.

Action	Specification/Repair	Next Step
Check for active fault codes.	Active fault codes? YES Repair : Troubleshoot the appropriate fault code. Reference the Marine Auxiliary QSB7-DM CM850 Fault Code Troubleshooting Manual, Bulletin 4325972, Section TF; or ISM and QSM 11 Electronic Control System Troubleshooting and Repair Manual, Bulletin 3666266, Section TF; or X15 CM2350 X125M Fault Code Troubleshooting Manual, Bulletin 5504346, Section TF; or the equipment manufacturer service information.	Repair complete
	Active fault codes? NO	2A

STEP 2. Check the shutdown unit.

STEP 2A. Check for buzzer function at the shutdown unit.

Conditions :

- No fault code registered at the shutdown unit.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for buzzer function at the shutdown unit.	Does buzzer function? YES	3A
	Does buzzer function? NO Repair : Replace the shutdown unit. Contact a Cummins® Authorized Repair Location.	Repair complete

STEP 3. Clear the fault codes.

STEP 3A. Clear the inactive fault codes.

Conditions :

- Turn keyswitch ON.
- Check the control panel for inactive fault codes.

Action	Specification/Repair	Next Step
Clear the inactive fault codes. • Check the inactive fault codes.	All fault codes cleared? YES	Repair complete
	All fault codes cleared? NO Repair : Troubleshoot any remaining fault codes.	Contact a Cummins® Authorized Repair Location