

Trainings ▾

Maintenance Check

Inspect the engine mounts for rubber deterioration, age hardening, and broken or lost bolts. Replace any broken or lost bolts and damaged rubber.

Tighten the engine mounting nuts and bolts.

Torque Value: 109 to 136 n•m [80 to 100 ft-lb]

