

Trainings ▾

Install

Install the nozzles, washers, and capscrews.

Tighten the capscrews.

Torque Value: 28 n•m [21 ft-lb]

Note : The crankshaft **must** be rotated to allow access to install all the nozzles.

