

Trainings ▾

Install

Start the tube nuts on all tubes before locating the sensor adapter.

Position the adapter onto the air intake manifold, as illustrated in the graphic.

Pre-start the mounting capscrews through the adapter into the air intake manifold.

Tighten the capscrews.

Torque Value: 20 n•m [180 in-lb]

