

Trainings ▾

Remove

Remove the capscrew and nut that attaches the EGR cooler connection heat shield.

Remove the EGR cooler connection heat shield.

