

Trainings ▾

Schedule											
Kilometers x 1000		48	80	200	400	480	800				
Miles x 1000		30	50	125	250	300	500				
Hours		1000	1500	3000	6000	6750	10000				
Months		6									
Years			1		2		5				
Procedure	Step										
Lubricating Oil and Filters (/qs3/pubsys2/xml/en/procedures/377/377-007-002.html)	Change	See Lubricating Oil and Filter Intervals procedure. Refer to Procedure 359-009 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-009.html)									
Pressure Fuel Filter (/qs3/pubsys2/xml/en/procedures/377/377-006-065-om.html)	Change	See Fuel Filter Intervals procedure. Refer to Procedure 359-008 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-008.html)									
Fuel Filter Suction (/qs3/pubsys2/xml/en/procedures/377/377-006-066-om.html) ¹	Change	See Fuel Filter Intervals procedure. Refer to Procedure 359-008 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-008.html)									
1. See equipment manufacturer service information.											
2. If equipped.											

Kilometers x 1000		48	80	200	400	480	800					
Miles x 1000		30	50	125	250	300	500					
Hours		1000	1500	3000	6000	6750	10000					
Months		6										
Years			1		2		5					
Procedure	Step											
Lubricating Oil and Filters (/qs3/pubsys2/xml/en/procedures/377/377-007-002.html)	Change	See Lubricating Oil and Filter Intervals procedure. Refer to Procedure 359-009 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-009.html)										
Pressure Fuel Filter (/qs3/pubsys2/xml/en/procedures/377/377-006-065-om.html)	Change	See Fuel Filter Intervals procedure. Refer to Procedure 359-008 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-008.html)										
Fuel Filter Suction (/qs3/pubsys2/xml/en/procedures/377/377-006-066-om.html) ¹	Change	See Fuel Filter Intervals procedure. Refer to Procedure 359-008 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-008.html)										
1. See equipment manufacturer service information.												
2. If equipped.												

Kilometers x 1000		48	80	200	400	480	800					
Miles x 1000		30	50	125	250	300	500					
Hours		1000	1500	3000	6000	6750	10000					
Months		6										
Years			1		2		5					
Procedure	Step											
Radiator Pressure Cap (/qs3/pubs/ys2/xml/en/procedures/377/377-008-047-om.html)	Check	X										
Supplemental Coolant Additive (SCA) and Antifreeze Concentration (/qs3/pubs/ys2/xml/en/procedures/99/99-008-046.html)	Check	X										
Charge Air Cooler (/qs3/pubs/ys2/xml/en/procedures/99/99-010-027.html)	Check	X										
1. See equipment manufacturer service information.												
2. If equipped.												

Kilometers x 1000		48	80	200	400	480	800					
Miles x 1000		30	50	125	250	300	500					
Hours		1000	1500	3000	6000	6750	10000					
Months		6										
Years			1		2		5					
Procedure	Step											
Cooling Fan Belt Tensioner (/qs3/pubs/ys2/xml/en/procedures/377/377-008-087.html)	Check		X									
Engine Wiring Harness (/qs3/pubs/ys2/xml/en/procedures/377/377-019-043-om.html)	Check		X									
Radiator Hoses (/qs3/pubs/ys2/xml/en/procedures/99/99-008-045.html)	Check			X								
Cold Starting Aid (/qs3/pubs/ys2/xml/en/procedures/377/377-010-029.html)	Check			X								
1. See equipment manufacturer service information.												
2. If equipped.												

Kilometers x 1000		48	80	200	400	480	800					
Miles x 1000		30	50	125	250	300	500					
Hours		1000	1500	3000	6000	6750	10000					
Months		6										
Years			1		2		5					
Procedure	Step											
Radiator Shutter Assembly (/qs3/pubs ys2/xml/en /procedures/377/377- 008- 049.html)	Check			X								
Vibration Damper, Viscous (/qs3/pubs ys2/xml/en /procedures/99/99- 001- 052.html)	Check			X								
Engine Mounting Bolts (/qs3/pubs ys2/xml/en /procedures/377/377- 000- 008.html)	Check			X								
1. See equipment manufacturer service information.												
2. If equipped.												

Kilometers x 1000		48	80	200	400	480	800					
Miles x 1000		30	50	125	250	300	500					
Hours		1000	1500	3000	6000	6750	10000					
Months		6										
Years			1		2		5					
Procedure	Step											
Engine Steam Cleaning (/qs3/pubsys2/xml/en/procedures/99/99-000-009.html)	Clean			X								
Aftertreatment Diesel Particulate Filter (/qs3/pubsys2/xml/en/procedures/377/377-011-041.html)	Check	See Aftertreatment Diesel Particulate Filter Intervals procedure. Refer to Procedure 359-006 in Section 3. (/qs3/pubsys2/xml/en/procedures/377/377-359-006.html)										
Coolant Filter (/qs3/pubsys2/xml/en/procedures/377/377-008-006-om.html) ²	Change				X							
Cooling System (/qs3/pubsys2/xml/en/procedures/377/377-008-018-om.html)	Flush				X							
1. See equipment manufacturer service information.												
2. If equipped.												

Kilometers x 1000		48	80	200	400	480	800					
Miles x 1000		30	50	125	250	300	500					
Hours		1000	1500	3000	6000	6750	10000					
Months		6										
Years			1		2		5					
Procedure	Step											
Overhead Set (/qs3/pubs ys2/xml/en /procedures/377/377- 003-004- om.html)	Adjust						X					
Air Shutoff Valve (/qs3/pubs ys2/xml/en /procedures/377/377- 010-143- om.html) ²	Change						X					
1. See equipment manufacturer service information.												
2. If equipped.												