

Trainings ▾

General Information

This procedure is for engines with 4 valves per cylinder only.

©Cummins Inc.

Install

Note : The crosshead has a round and oval hole. If installing new crossheads, it is **not** required to place the holes in a particular position. If crossheads are being reused, make sure to install them in their original location and orientation.

Install the crossheads on the valve stems.

