

Trainings ▾

Adjust

The amount of fuel injected, and subsequently the speed and power from the engine, is controlled by the fuel control lever. Restricted travel of the lever can cause low power. **Always** check for full travel of the lever when diagnosing a low-power complaint.

