


Trainings ▾

Initial Check

Measure the fuel lift pump inlet restriction with a vacuum gauge between the fuel lift pump inlet and the supply line (4) from the fuel tank.



Fuel Lift Pump Inlet Restriction - Clean Fuel Filter


kpa		in-hg
63.5	MAX	2.5

Fuel Lift Pump Inlet Restriction - Dirty Fuel Filter


kpa		in-hg
100	MAX	4.0

If the inlet restriction is above the maximum, check for restrictions or suction leaks in the fuel circuit to the fuel lift pump:

1. Supply line
2. Prefilter
3. Supply line
4. Supply tank
5. Tank vent.



Look for a plugged supply tank vent first.




Fuel prefilters, in-line and water separator type, can become clogged and cause a loss of fuel flow.

Check the prefilter for clogs or restrictions.


In cold weather, check the prefilter for gelled fuel.

Clean or replace the prefilter, if necessary.



Check for kinks or bends in the fuel supply line that can cause a restriction in the fuel flow.

Remove and blow out the fuel supply lines.



Test


Output Pressure Test (Diaphragm Style and Piston Style - Low Output)

Operate the engine and measure the output pressure of the fuel lift pump using an in-line pressure gauge at the inlet to the injection pump.


The minimum pressure at high idle is 21 kPa [3 psi].

If the minimum pressure is not achieved, check for:

- Dirty fuel filter
- Damaged lift pump.



Note : On some engines, the diaphragm style pump may have been replaced by a low output piston style pump. The specifications below apply to both diaphragm and piston low output pumps. The low output piston pump is visually different from higher output piston pump. The outlet points downward on the low output piston pump.



Output Pressure Test (Piston Style - High Output)

Operate the engine, and measure the output pressure of the fuel lift pump with an in-line pressure gauge at the inlet to the injection pump.

Minimum pressure at high idle is 124 kPa [18 psi].

If the minimum pressure is not achieved, check for:

- Dirty fuel filter
- Damaged lift pump.

