

Trainings ▾

Remove

B4.5 RGT Engines

Remove the fuel connector retaining nut.

Install the fuel connector remover, Part Number 3164025.

Note : When removing the fuel connector from the cylinder head, care must be taken to make sure the connector o-ring is **not** damaged.

Remove the fuel connector from the cylinder head.

