

Trainings ▾

Install

Install the tensioner and capscrew.

Torque Value: 43 n•m [32 ft-lb]

