

Fault Acknowledge Not Operational

Symptoms

- Pressing the button on the ED-4 display does **not** acknowledge the alarm.

How To Use This Tree

This symptom tree can be used to troubleshoot ED-4 display issues. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- Possible causes are:
- Display software
 - ED-4 display (button).
- Verify failure 2 independent systems? Faults **must** be acknowledged per engine.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the display software.	
	STEP 1A. Verify active fault.	Fault acknowledge possible with ED-4 display?
	STEP 1B. Check display software.	Later software revision for the ED-4 display?
	STEP 1C. Validate fault acknowledgement.	Fault acknowledge possible with ED-4 display?

STEP 1. Check the display software.

STEP 1A. Check for an inactive alarm message.

Conditions :

- Turn system enable switch OFF.
- Disconnect the engine coolant temperature sensor from the engine harness.
- Turn system enable switch ON.

Action	Specification/Repair	Next Step
• Wait 30 seconds, monitor ED-4 display. • Verify coolant temperature sensor fault. With ED-4 displays on independent systems, fault must be acknowledged per engine	Fault acknowledge possible with ED-4 display? YES Repair : ED-4 display is working properly.	Repair complete.
	Fault acknowledge possible with ED-4 display? NO	1B

STEP 1B. Check display software.**Conditions :**

- Turn enable switch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check Cummins® QuickServe® On-line webpage for the latest software to ED-4 display. Reference Procedure 015-075 in Section 15 of the appropriate service manual.	Later software revision for the ED-4 display? YES Repair : Download the latest software to the ED-4 display. Reference Procedure 015-075 in Section 15 of the appropriate service manual.	1C
	Later software revision for the ED-4 display? NO Repair : Replace the ED-4 display. Refer to Procedure 015-035 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-035.html)	Repair complete.

STEP 1C. Validate fault acknowledgement.

Conditions :

- Turn system enable switch OFF.
- Disconnect the engine coolant temperature sensor from the engine harness.
- Turn system enable switch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

• Wait 30 seconds. Monitor ED-4 display. • Verify coolant temperature sensor fault.	Fault acknowledge possible with ED-4 display? YES Repair : The download of the latest software corrected the issue.	Repair complete.
	Fault acknowledge possible with ED-4 display? NO Repair : Replace the ED-4 display. Refer to Procedure 015-035 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-035.html)	Repair complete.