

Trainings ▾

Remove

Mark the gears before disassembly so proper reassembly can occur or align the factory timing marks. Cummins Inc., recommends measuring the camshaft idler gear end clearance before removing the gear.

Remove the four mounting capscrews, thrust retainer plate, thrust bearing, and the left bank camshaft idler gear

Remove the idler shaft.

