

Trainings ▾

Remove

The bolt-in idler shafts have a flange that requires the shaft, idler gear, and thrust washer to be removed as an assembly.

Mark the position of the idler shaft before removing it.

Remove the three capscrews, retainer, and thrust washer from the idler gear shaft.

Remove the idler gear, thrust washer, and shaft as an assembly from the engine.

Remove the idler gear and thrust washer from the shaft.

