

FAULT CODE 612 - Engine Oil Filter Differential Pressure - Data Valid But Below Normal Operating Range - Most Severe Level

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Troubleshoot the fault code.	
	STEP 1A. Reference the appropriate procedure.	
STEP 2.	Clear the fault code.	
	STEP 2A. Disable the fault code.	
	STEP 2B. Clear the inactive fault codes	

STEP 1. Troubleshoot the fault code.

STEP 1A. Reference the appropriate procedure.

Conditions :		
Action	Specification/Repair	Next Step
Reference the Lubricating Oil Filter Restriction is High symptom tree in Section TS of this manual.	Lubricating Oil Filter restriction within specifications.	2A
	Reference the "Lubricating Oil Filter Restriction is High" symptom tree in Section TS of this manual.	1A

STEP 2. Clear the fault code.

STEP 2A. Disable the fault code.

Conditions :

- Connect all components.

Action	Specification/Repair	Next Step
Disable the fault code. • Start the engine and let it idle for 1 minute. • Use INSITE™ electronic service tool to verify Fault Code 612 is inactive.	Fault Code 612 inactive	2B
	Return to the troubleshooting steps, or contact a Cummins® Authorized Repair Location if all steps have been completed and checked again.	1A

STEP 2B. Clear inactive fault codes.

Conditions :

- Connect all components.

Action	Specification/Repair	Next Step
Clear inactive fault codes. • Use INSITE™ electronic service tool to clear all inactive fault codes.	All fault codes cleared	Repair complete
	Troubleshoot any remaining active fault codes.	Appropriate troubleshooting charts