

Trainings ▾

Maintenance Check

Engine mounts that act as isolators are not supplied by Cummins Inc. Refer to the equipment manual for maintenance or contact the OEM.

Check the torque on the nuts and bolts. Tighten any that are loose. Inspect the rubber for deterioration and age hardening. Replace any broken or lost bolts, capscrews, or damaged rubber.

Capscrew size and grade vary with the flywheel housing and mounting arrangement. Determine the size and grade of the mounting bolts. Refer to the capscrew torque values in Section V of this manual.

