

Trainings ▾

General Information

Fuel filter change intervals are based on the following:

- Fuel consumption.

Note : Extending the fuel filter change interval beyond recommended will decrease engine life due to corrosion, depositions, and wear.

Suction-Side Fuel Filter Change Interval Fuel Consumption

Check the suction-side fuel filter during oil drain maintenance intervals. See Lubricating Oil and Filter Intervals procedure. Refer to Procedure 359-009 (</qs3/pubsys2/xml/en/procedures/377/377-359-009.html>) in Section 3.

To check the suction-side fuel filter, see equipment manufacture service information.

Suction-side fuel filters are OEM installed and can vary based on OEM hardware selection and fuel quality.

Pressure-Side Fuel Filter Change Interval Fuel Consumption

Extreme Severe < 1.27 km/liter [3 mpg]	Severe 1.27 to 2.1 km/liter [3 to 4.9 mpg]	Short Haul 2.1 to 2.5 km/liter [5 to 5.9 mpg]		Normal 2.5 to 3 km/liter [6 to 6.9 mpg]		Light > 3 km/liter [7 mpg]	
Standard	Standard	Standard	Extended d(1)(2)(3)	Standard	Extended d(1)(2)(3)	Standard	Extended d(1)(2)(3)
7,000 km [4,500 mi]	40,000 km [25,000 mi]	64,000 km [40,000 mi]	81,000 km [50,000 mi]	81,000 km [50,000 mi]	97,000 km [60,000 mi]	97,000 km [60,000 mi]	121,000 km [75,000 mi]

1. An Extended Life FF5971NN pressure-side fuel filter is recommended to achieve this interval and align with the oil drain interval.
2. To fit an Extended Life FF5971NN pressure-side fuel filter, an upfit is required. See Installation Instruction, Thermal Recirculation Valve Upfit Kit, Bulletin 5414689.
3. A Davco 400 series, or equivalent, capacity suction-side filter is recommended to align the suction-side filter change interval with the oil drain interval.

