

Trainings ▾

Maintenance Check

Automotive Applications

(If equipped)

Every 80,000 km [50,000 mi], 1500 hours, or 1 year, remove the wing nut that secures the cover to the housing. Remove the cover and the element. Clean the cover and the housing with a clean cloth. Inspect air cleaner cover and housing for signs of corrosion. Inspect the rubber gasket on the center bolt.

Replace, if damaged.

Note : Air cleaner cover and housing corrosion can allow debris and unfiltered air to enter the air compressor intake. This will cause premature air compressor failure.

