

Trainings ▾

General Information

Preventative maintenance begins with day-to-day awareness of the system. Prior to engine operation, check for the following:

- Excessive oil, coolant, or fuel consumption
- Leaks
- Loose or damaged parts
- Worn or damaged belts
- Worn or damaged wiring harnesses
- Any change in system appearance
- Odor of fuel
- Odor of electronic devices.

When operating the engine, listen for any unusual system noises which can indicate service is required.

Take appropriate action to rectify any abnormalities or contact a Cummins® Authorized Repair Location.

Schedule

The following daily maintenance schedule lists inspections and procedures which **must** be performed on a daily basis to properly maintain the engine.

Daily Maintenance

- Air Intake Piping - Check
- Coolant Level - Check
- Fan, Cooling - Check
- Lubricating Oil Level - Check
- Radiator Hoses - Check
- Throttle Response Test - Check
- Air Cleaner Restriction - Check
- Air Tanks and Reservoirs - Drain
- Charge Air Piping - Check
- Closed Crankcase Ventilation Hoses - Check
- Drive Belts - Check

- Aftertreatment Exhaust Piping - Check
- Fuel Filter (Spin-On Type), if equipped - Drain
- Fuel Filter (Canister Type), if equipped - Drain
- Rocker Lever Cover (Pressure Relief Valve) - Check¹.

¹When the ambient temperature is below 0°C [32°F].

Last Modified: 30-Jan-2024
