

General Information

Duty cycle intervals are based on the idle time, fuel consumption, and Gross Vehicle Weight (GVW).

Determine the duty cycle. See Table 1, Duty Cycle Identification.

- If any condition under "Extreme" applies, the duty cycle is "Extreme."
- If any condition under "Severe" applies, and no conditions under "Extreme" apply, the duty cycle is "Severe."
- If any condition under "Normal" applies, and no conditions under "Severe" apply, the duty cycle is "Normal."

Table 1, Duty Cycle Identification			
Conditions	Duty Cycle		
	Normal	Severe	Extreme
Idle time	Less than 40%	Greater than 40%	-
Fuel consumption	Less than 40 kg/100 km [142 lb/100 miles]	40 kg/100 km [142 lb/100 miles] to 55 kg/100 km [195 lb/100 miles]	Greater than 55 kg/100 km [195 lb/100 miles]
GVW	Less than 49 tonnes [108,027 lb]	Greater than 49 tonnes [108,027 lb]	-