

Trainings ▾

ECM Dataplate

The external ECM dataplate is located on top of the ECM.

The dataplate contains the ECM part number (P/N), ECM serial number (S/N), manufacturing date code (D/C), engine serial number (ESN), and ECM code.

