

Trainings ▾

Remove

Remove the four cooling plate mounting capscrews.

Do **not** lose any of the heat-resistant grommets. They are on both sides of the cooling plate.

One of the mounting locations has heat-resistant star washer grommets on both sides of the cooling plate.

Remove the cooling plate.

