

Trainings ▾

Remove

Different engine applications can have the fuel filter bracket and filter head mounted at different locations on the engine. Some engines have a pump mounted filter head.

Remove the four mounting capscrews.

Remove the fuel filter head bracket.

