

Trainings ▾

Install

Use a new gasket and install the filter head to the cylinder block.

Install the nine capscrews and tighten.

Torque Value: 47 n•m [35 ft-lb]

