

Trainings ▾

Install

⚠ WARNING ⚠

The regulator spring must be compressed to install the retainer plug. Personal injury can result. Wear face and eye protection.

Note : A counterbore plunger and orifice is unique to engines with a viscosity sensor. Low oil pressure will result if a solid plunger is used with a viscosity sensor.

Install the regulator plunger (3) and regulator spring (2).

Install and tighten the retainer plug (1).

Torque Value:

Rear Sump Oil Pan 75 n•m [55 ft-lb]

Torque Value:

Front Sump Oil Pan 122 n•m [90 ft-lb]

Torque Value:

Center Sump Oil Pan 75 n•m [55 ft-lb]

