

## Trainings ▾

## Install

Install the belt tensioner.

Install and tighten capscrews.

**Torque Value:** 47 n•m [ 35 ft-lb ]

